COMPONENTS:

- (1) Trisodium phosphate; Na₃PO₄; [7601-54-9]
- (2) 2-Propanone (acetone); C₃H₆O; [67-64-1]
- (3) Water; H₂O, [7732-18-5]

ORIGINAL MEASUREMENTS:

- Nirenberg, Z.; Solenchyk, B.; Yaron, I.
- J. Chem. Eng. Data 1977, 22, 47-8.

VARIABLES:

Composition and temperature.

PREPARED BY:

J. Eysseltová

EXPERIMENTAL VALUES:

I. Ternary solid-liquid equilibrium in the ${\rm Na_3PO_4-C_3H_6O-H_2O}$ system.

	$^{\text{Na}}3^{\text{PO}}4$	^C 3 ^H 6 ^O	H ₂ O		Na ₃ PO ₄	^C 3 ^H 6 ^O	H ₂ 0
t/°C	mass%	mass%	mass%	t/°C	mass%	mass%	mass%
10 10 10 10	4.65 2.43 1.06 0.50 0.20	8.10 15.75 24.10 33.30	95.35 89.47 83.19 75.40 66.50	20 20 20 20 20 20	7.73 3.20 1.30 0.75 0.17	7.98 16.75 26.40 32.46	92.27 88.82 81.95 72.85 67.37
31.5 31.5 31.5 31.5 31.5 31.5	6.00 3.00 0.62 0.34 0.19	6.57 13.70 24.87 34.40 42.60 52.00	89.26 87.43 83.30 74.50 65.06 57.20 47.93	40 40 40 40 40 40	15.10 8.80 4,90 2.25 0.90 0.27 0.09	5.95 14.10 23.50 34.10 44.50 52.00	84.90 85.25 81.00 74.25 65.00 55.23 47.91

X-ray diffraction showed that the solid phase was $\mathrm{Na_3P0_4\cdot12H_2O}$ and remained unaltered.

(continued next page)

AUXILIARY INFORMATION

METHOD/APPARATUS/PROCEDURE:

Acetone-water mixtures were placed in flasks in a thermostat. In experiments at 31.5°C the phosphate was progressively added to the solvent until saturation was reached. When acetone/water ratios exceeded 2/3, a 9% water solution of $Na_3PO_4 \cdot 12H_2O$ was added in aliquots of 0.5 ml. At other temperatures an excess of phosphate was always added. Mixtures were equilibrated for 24 hours. Samples were taken, diluted immediately and analyzed for Na, $\rm P_2O_5$ and acetone. Phosphorus was determined spectrophotometrically at 426 nm using the vanadamolybdate method. Acetone was determined iodometrically. Sodium was determined using a Pye Unicam SP90 spectrometer.

SOURCE AND PURITY OF MATERIALS:

Analytical reagent grade materials were used and the purity was rechecked. Doubly distilled water was used in all experiments.

ESTIMATED ERROR:

Temperature was controlled to within ± 0.1 K P20s: accuracy ±0.25 ppm at 50 ppm; acetone: accuracy ±0.048 mg; Na: accuracy ± 2 ppm at 200 ppm.

REFERENCES:

COMPONENTS:

ORIGINAL MEASUREMENTS:

- (1) Trisodium phosphate; Na₃PO₄; [7601-54-9] Nirenberg, Z.; Solenchyk, B.; Yaron, I.
- (2) 2-Propanone (acetone); C₃H₆O; [67-64-1]
- (3) Water; H₂O; [7732-18-5]

J. Chem. Eng., Data 1977, 22, 47-8.

EXPERIMENTAL VALUES cont'd:

II. Solubility isotherms in the $\mathrm{Na_3PO_4-C_3H_60-H_20}$ system in various ratios of acetone to 100 ml of solution.

	10°C		20°C		31.5°C	
m1/100m1	Na ₃ PO ₄ g/100 m1	sp.gr.	Na ₃ PO ₄ g/100 ml	sp. gr.	Na ₃ PO ₄ g/.100 ml	sp. gr.
0 10 20 30 40 50 60	4.86 2.37 1.05 0.47 0.19 trace 0	1.04 0.98 0.98 0.97 0.95	8.35 3.30 1.25 0.72 0.16 trace 0	1.08 1.02 0.98 0.95 0.94	11.50 6.39 3.02 0.61 0.32 0.18 0.07	1.07 1.05 1.00 0.96 0.93 0.90
	40°	С				
0 10 20 30 40 50 60	17.05 9.67 5.11 2.25 0.87 0.26 0.08	1.13 1.10 1.04 1.00 0.97 0.94 0.91				