COMPONENTS: (1) 2-Methylhexane; C₇H₁₆; [591-76-4] (2) Water; H₂O; [7732-18-5] VARIABLES: Temperature: 10-30°C CARIGINAL MEASUREMENTS: Englin, B.A.; Plate, A.F.; Tugolukov, V.M.; Pryanishnikova, M.A. Khim. Tekhnol. Topl. Masel 1965, 10, 42-6. PREPARED BY: A. Maczynski and M.C. Haulait-Pirson

EXPERIMENTAL VALUES:

Solubility of water in 2-methylhexane

t/°C	g(2)/100 g sln	$\frac{10^4 x_2}{}$ (compiler)
10	0.0056	3.12
20	0.0103	5.73
30	0.0182	10.12
30	0.0102	10.12

AUXILIARY INFORMATION

METHOD/APPARATUS/PROCEDURE: Component (1) was introduced into a thermostatted flask and saturated for 5 hours with (2). Next, calcium hydride was added and the evolving hydrogen volume measured and hence the concentration of (2) in (1) was evaluated. ESTIMATED ERROR: not specified. ESTIMATED ERROR: not specified. REFERENCES:

COMPONENTS:

- (1) 2-Methylhexane; C₇H₁₆; [591-76-4]
- (2) Water; H₂O; [7732-18-5]

ORIGINAL MEASUREMENTS:

Price, L.C.

Am. Assoc. Petrol. Geol. Bull. 1976, 60, 213-44.

VARIABLES:

One temperature: 25°C

PREPARED BY:

M.C. Haulait-Pirson

EXPERIMENTAL VALUES:

The solubility of 2-methylhexane in water at 25°C and at system pressure was reported to be 2.54 mg(1)/kg(2). The corresponding mass percent and mole fraction, x_1 , calculated by the compiler are 2.54 x 10^{-4} g(1)/100 g sln and 4.57 x 10^{-7} .

AUXILIARY INFORMATION

METHOD/APPARATUS/PROCEDURE:

The solubility was determined at laboratory temperatures by use of screw-cap test tubes. The (1) phase floated on top of the water and insured saturation of the (2) phase in 2 to 4 days. Analyses were carried out by GLC using a Hewlett-Packard model 5751 gas chromatograph with dual-flame ionization detectors. Many details are given in the paper.

SOURCE AND PURITY OF MATERIALS;

- (1) Phillips Petroleum Company; Chemical Samples Company or or Aldrich Chemical Company; 99+%.
- (2) distilled.

ESTIMATED ERROR:

temp. ± 1 K

soly. \pm 0.02 mg(1)/kg(2)

REFERENCES:

COMPONENTS: (1) 2-Methylhexane; C₇H₁₆; [591-76-4] (2) Water; H₂O; [7732-18-5] VARIABLES: One temperature: 25°C ORIGINAL MEASUREMENTS: Krzyzanowska, T.; Szeliga, J. Nafta (Katowice) 1978, 12, 413-7. PREPARED BY: M.C. Haulait-Pirson

EXPERIMENTAL VALUES:

The solubility of 2-methylhexane in water at 25°C was reported to be $2.54 \, \text{mg}(1)/\text{kg}(2)$.

The corresponding mass percent and mole fraction, x_1 , calculated by compiler are 2.54 x 10^{-4} g(1)/100 g sln and 4.57 x 10^{-7} .

Editor's Note: Based on the results for this and other hydrocarbon-water systems, uncertainity exists about whether the datum compiled here is independent of that of Price for the same system (see previous page). Consequently, this system has not been evaluated.

AUXILIARY INFORMATION

METHOD/APPARATUS/PROCEDURE:

Saturated solutions of (1) in (2) were prepared in two ways. First, 200 µL of (1) was injected into 20 mL of (2) and thermostatted at 25°C. Second, the mixture of (1) and (2) as above was thermostatted at 70°C and then cooled to 25°C. The time required to obtain equilibrium was three weeks. The solubility of (1) in (2) was measured by glc. A Perkin-Elmer model F-11 gas chromatograph equipped with a 100-150 mesh Porasil column (70°C) and a flame ionization detector was used. Saturated solutions of heptane in (2) were used as standard solutions.

SOURCE AND PURITY OF MATERIALS:

- (1) not specified.
- (2) not specified.

ESTIMATED ERROR:

soly. 0.09 mg(1)/kg(2) (standard
deviation from 7-9 determinations)

REFERENCES: